

## Homework 3:

### Calling Mutations with Samtools/Bcftools

Since I have already aligned the reads in Homework 2, the next step is to call mutations (variants) using Samtools and Bcftools. Below is a high-level overview of the steps involved.

#### Step 1: Download the Reference Genome (hg19)

To perform mutation calling, you need to download the hg19 reference genome. Run the following command in your terminal:

```
wget http://hgdownload.cse.ucsc.edu/goldenpath/hg19/bigZips/hg19.fa
```

#### Step 2: Generating Variant Calls in VCF Format Using Bcftools

Once the `hg19.fa` reference genome and the aligned, sorted BAM file (`ENCFF002DKA_DKE_Aligned_Sorted.bam`) are available, you can call variants using Bcftools.

##### 1. Generate Raw SNP Calls

Run the following command to generate raw SNP calls:

```
bcftools mpileup -Ov -f ./hg19.fa ENCFF002DKA_DKE_Aligned_Sorted.bam -o  
ENCFF002DKA_DKE_Aligned_Sorted_rawSNP.vcf
```

##### Explanation of the command:

- `bcftools mpileup`: Generates a pileup of reads at each position.
- `-O v`: Outputs the file in VCF format (instead of BCF).
- `-f ./hg19.fa`: Specifies the reference genome.
- `ENCFF002DKA_DKE_Aligned_Sorted.bam`: The aligned and sorted BAM file.

- `-o ENCF002DKA_DKE_Aligned_Sorted_rawSNP.vcf`: Outputs the raw SNP calls to this file.

```
zsh: command not found: -zsh
Mohana_Alla 🤔🤔🤔 ~ % bcftools mpileup -Ov -f ./hg19.fa ENCF002DKA_DKE_Aligned_Sorted.bam -o ENCF002DKA_DKE_Aligned_Sorted_rawSNP.vcf
[mpileup] 1 samples in 1 input files
[mpileup] maximum number of reads per input file set to -d 250
Mohana_Alla 🤔🤔🤔 ~ % bcftools call -mv -Ov -o ENCF002DKA_DKE_Aligned_Sorted_calledSNP.vcf ENCF002DKA_DKE_Aligned_Sorted_rawSNP.vcf
Note: none of --samples-file, --ploidy or --ploidy-file given, assuming all sites are diploid
Mohana_Alla 🤔🤔🤔 ~ % bcftools stats ENCF002DKA_DKE_Aligned_Sorted_calledSNP.vcf >ENCF002DKA_DKE_Aligned_Sorted_calledSNP_stats.txt
Mohana_Alla 🤔🤔🤔 ~ % █
```

## 2. Call Variants Using Bcftools

After generating the raw pileup, call actual mutations using:

```
bcftools call -mv -Ov -o ENCF002DKA_DKE_Aligned_Sorted_variants.vcf
ENCF002DKA_DKE_Aligned_Sorted_rawSNP.vcf
```

### Explanation:

- `bcftools call`: Calls SNPs and Indels.
- `-m`: Uses the multiallelic caller.
- `-v`: Outputs variants only (excludes sites with no variation).
- `-O v`: Outputs the file in VCF format.
- `-o ENCF002DKA_DKE_Aligned_Sorted_variants.vcf`: The final variant file.

## Step 3: Analyzing Variant Statistics Using Bcftools

Once the VCF file (`ENCFF002DKA_DKE_Aligned_Sorted_calledSNP.vcf`) is generated, analyze the basic statistics of the variants.

### 1. Running Bcftools Stats

Run the following command to generate variant statistics:

```
bcftools stats ENCFF002DKA_DKE_Aligned_Sorted_calledSNP.vcf >
ENCFF002DKA_DKE_Aligned_Sorted_calledSNP_stats.txt
```

**Explanation:**

- `bcftools stats`: Generates summary statistics of the VCF file.
- `ENCFF002DKA_DKE_Aligned_Sorted_calledSNP.vcf`: Input VCF file containing called variants.
- `> ENCFF002DKA_DKE_Aligned_Sorted_calledSNP_stats.txt`: Redirects output to a text file.

## Step 4: Visualizing the HBD Gene Region in IGV

To visualize the HBD gene region in your aligned data, follow these steps:

### 1. Load the BAM File into IGV

- Open IGV and click **"File"** → **"Load from File"**.
- Select the BAM file: `ENCFF002DKA_DKE_Aligned_Sorted.bam`.

### 2. Navigate to the HBD Gene Region

- In the IGV search bar, enter:  
HBD
- Press **Enter** to visualize the region.



## Detailed Summary of Mutation Results

### 1. Variant Counts and Distribution

- **Total Variants Identified:** 1,112,892
- **SNPs (Single Nucleotide Polymorphisms):** 944,664 (~85% of total variants)
- **Indels (Insertions/Deletions):** 168,228 (~15% of total variants)
- **Multiallelic Sites:** 5,466
- **Multiallelic SNP Sites:** 118

#### Interpretation:

The majority of detected variants are SNPs, which is expected in genomic mutation analysis. The presence of multiallelic sites suggests some regions contain multiple alternate alleles.

### 2. Transition/Transversion Ratio (Ts/Tv)

- **Transitions (Ts):** 626,807

- **Transversions (Tv):** 317,975
- **Ts/Tv Ratio:** 1.97

#### Interpretation:

The Ts/Tv ratio is close to 2, which is normal for human genomes. Transitions (A↔G, C↔T) occur more frequently than transversions (A↔C, A↔T, C↔G, G↔T) due to mutation bias and selective pressure.

### 3. Allele Frequency (AF) Distribution

- **Singleton Mutations (AF = 0.000):** 308,439 SNPs
- **High-Frequency Variants (AF = 0.99):** 636,343 SNPs

#### Interpretation:

A large number of singleton variants suggests many rare mutations in the dataset. The presence of high-frequency variants (AF = 0.99) indicates that some SNPs are common polymorphisms found in the population.

### 4. Variant Quality Distribution

- **Quality scores range:** 3 to >90
- **Majority of variants:** Quality scores between 3 and 40

#### Interpretation:

Many variants have low-quality scores, indicating the need for filtering (**QUAL ≥ 20**) to remove low-confidence mutations. A higher quality threshold ensures that only reliable variants are retained for downstream analysis.

## Recommendations and Next Steps

### 1. Filtering Variants

- Remove low-quality variants using a threshold of **QUAL ≥ 20** and **DP ≥ 10** for reliable calls.

### 2. Variant Annotation

- Use tools such as **ANNOVAR**, **SnpEff**, or **VEP** to predict the functional impact of variants (e.g., missense/nonsense mutations).

### 3. Visualization in IGV

- Load aligned BAM files into IGV and inspect key gene regions (e.g., **HBD gene**) to validate mutations.

### 4. Further Statistical Analysis

- Compare identified SNPs and Indels with known disease-associated mutations and population databases.

## Final Conclusion

This mutation analysis reveals a high number of SNPs, a Ts/Tv ratio consistent with human genomes, and a mix of rare and common variants. To improve dataset reliability, filtering, annotation, and IGV visualization are recommended to identify biologically significant mutations.